



Up Yours Performance Exhaust

1. Remove factory crap!! Remove factory exhaust flanges and install our pipe. Throw the rest in the garbage. **Shown in picture A**
2. Remove factory transmission bracket and replace with ours. (Note: If you have a 5 speed transmission you will need to space our bracket out with longer bolts). **Shown in picture B**
3. Install front heat shield with hose clamps facing down. Install exhaust tip. **Shown in picture C1, C2**
4. Install exhaust gaskets provided. (Note:S&S or factory gaskets will work or bubble gum)
5. Install pipe put rear pipe close to port and follow with front port. You will have to manipulate pipe to get it seated in port.
6. Use hardware provided to connect pipe to bracket. 2 (Large Washers) go between pipe and bracket. **Shown in picture D**
7. Install plugs or O2 sensors, double check plugs to insure that they are tight. Install the remaining heat shields and hose clamps facing up.
8. Kiss my ass (Just Kidding) ENJOY!!! **Shown in picture E**



A.



B.



C1.



C2.



D.



E.

Exhaust Warranty - Exhaust products are warranted against defects in material or workmanship for a period of 12 months from the date of the original invoice. This does not cover finishes such as plating or painted surfaces with discoloration or rust. Discoloration is not a warrantable item and is a result of improper fuel calibration, This warranty shall be limited to the repair or replacement of the defective part, which may be proven defective under normal use. Dirty Bird Concepts will not warranty any product that has been abused, misused, improperly installed, or modified. Any part that is repaired or replaced under this warranty will, itself, be warranted only for the remainder of the warranty period of the original product being repaired or replaced. This warranty is non-transferable and is limited to the original retail purchaser.