



Horn Installation Instructions

1. Install horn tighten bolt as shown picture A.
2. Install motor mount bracket shown picture B.
3. Remove factory motor mount shown picture C.
4. After hooking up the horn wires, install bracket shown picture D.
5. Once you see everything clears, send it to the painter and repeat steps after paint.

Please be sure thick washer stays between horn and bracket. If horn gets bound up when tightening, the nut will cause the horn to fail. Make sure fuel line has clearance on both sides so when motor shifts at idle it does not rub.

A.



B.



C.



D.

